

## Texas A&M University - Texarkana Hot Work Permit

Hot work is any operation that generates heat, spark or open flame. This includes, but is not necessarily limited to welding, cutting, grinding, soldering, torch applied roofing, heat gun uses and similar activities.

**Before initiating Hot Work, determine if there is a safer way to complete the work.**

Date: \_\_\_\_\_ Location: \_\_\_\_\_ Job#: \_\_\_\_\_

Type of Hot Work: ☐ Soldering ☐ Welding ☐ Cutting ☐ Roofing ☐ Other \_\_\_\_\_

**Hot Work Precautions Check List:** Complete prior to any hot work beginning in an area not designated for hot work. Check each box where the statement is true. If any statements are not true, then hot work should not begin until that issue has been safely resolved.

### Required Safety Precautions

- ☐ Fire suppression sprinklers, fire hoses or fire extinguishers are available and operable.
- ☐ Hot work equipment is operable and in good repair.
- ☐ Smoke/fire detectors in the immediate area of the hot work have been temporarily disabled until the hot work is complete.
- ☐ Building occupants have been protected or isolated from the hot work area.
- ☐ Drums, barrels and tanks have been cleaned and purged of flammables and toxics, all tank feeds are closed, and the tank is vented.

### Requirements within 35 feet:

- ☐ Area has been properly swept to remove any combustible debris.
- ☐ Flammable and ignitable materials and debris have been moved at least 35 feet from the hot work area or covered and protected with fire resistant materials.
- ☐ Cracks / holes in floors, walls & ceilings (including ductwork) are covered or plugged.
- ☐ Combustible floors covered with fire-resistive material.

### Requirements within 50 feet:

- ☐ Explosives, compressed gas cylinders or stored fuels have been moved at least 50 feet from the hot work area or have been protected from the hot work.

### Work on walls or ceilings:

- ☐ Construction is noncombustible and has no combustible covering or insulation.
- ☐ Areas adjacent to walls being worked on are checked for combustibles and any combustibles are either removed or protected.

**Fire Watch Required during Hot Work and a minimum of 30 minutes following completion of work.**

Yes \_\_\_\_\_ No \_\_\_\_\_ Name: \_\_\_\_\_

*A fire watch is needed for all hot work activities unless the hot work area has no fire hazards or combustible exposures. The fire watch must have fire-extinguishing equipment readily available and be trained in its use. They must also be familiar with the procedures for sounding an alarm in the event of a fire. The fire watch will watch for fires in the exposed areas and are responsible for extinguishing spot fires and communicating alarms immediately. The fire watch may be assigned other work duties while in the hot work area; however, they need to be vigilant in watching for fires.*

**POST THIS PERMIT NEAR WORK ENTRY AREA WHILE WORK IS IN PROGRESS**

**When work is completed:**

- ☐ Inspected work area, and any potentially affected surrounding areas, for fire, fire damage, or potential for fire.
- ☐ Reactivated smoke/fire detectors that were disabled because of the hot work.

**I verify that the above location has been examined, and the necessary precautions have been taken to prevent the outbreak of fire due to Hot Work.**

Worker Signature (Issued): \_\_\_\_\_ Date: \_\_\_\_\_ Time: \_\_\_\_\_

Worker Signature (Closed): \_\_\_\_\_ Date: \_\_\_\_\_ Time: \_\_\_\_\_

Supervisor Signature: \_\_\_\_\_ Date: \_\_\_\_\_ Time: \_\_\_\_\_

**THIS PERMIT IS ONLY VALID FOR THE DAY, PLEASE RETURN TO EHS WHEN WORK IS COMPLETE**

**WARNING!**

**HOT WORK IN PROGRESS**

**WATCH FOR FIRE!**

In case of FIRE call 6611 or 911

Emergency Numbers:  
UPD 6611 or 903-280-4149

EHS: 903-334-6794  
Cell: 620-727-7990